

Assembly Guide For Albany Carlton.

RECOMMENDED TOOLS: HAMMER, CORDLESS DRILL / SCREWDRIVER (BATTERY OPERATED IF AVAILABLE), STANLEY KNIFE, SAW, STEPLADDERS TO FELT ROOF. 10MM & 13MM SPANNER/ SOCKET ESTIMATED ASSEMBLY TIME: TWO PEOPLE 4 - 6 HOURS. WE RECOMMEND PILOT DRILLING SCREW HOLES FIRST.

PARTS LIST	
A: 2 X FLOOR SECTION	J: 2 X FRONT VERANDAH RAIL
B: 2 X WINDOW SIDE	K: 4 X ROLLS OF FELT (6 WITH VERANDAH)
C: 2 X PLAIN SIDE	L: 1 X TRIM PACK (STRIPS & FASCIAS)
D: 1 X DOOR SECTION	M: 2 X DIAMOND FINALS
E: 2 X PLAIN GABLE (+ TOPS)	N: 16 X DOOR GLASS
F: 2 X ROOF SECTION (4 ON 4.2 M)	O: 18 X WINDOW GLASS
G: 2 X VERANDAH FLOOR	P: 1 X FIXING & HANDLE PACK
H: 1 X VERANDAH ROOF (2 ON 4.2 M)	Q: 1 X ROOF PURLIN
I: 2 X END VERANDAH RAIL	R: 1 X ROOF TRUSS (4.2 M ONLY)

1. Lay the floor panels (A) in their desired position (remember to leave enough space around the building for roof overhang and maintenance). It is essential the floor is on a solid level base otherwise the building will not fit together properly and the door may not fit flush. Fix by nailing through the floor into the joining blocks. Place the panels around the floor - it will help you understand how they fit together.

2. Position a plain gable (E) at one end of the floor (the lip on the bottom overhangs the floor). While your assistant holds the gable place a plain side panel (C) on the floor to form a corner. Check that the sides are sitting flat on the floor and the panels are butted together, screw the gable into the side from the inside using two of the screws provided (hexagon head coach screws). Note the Carlton now comes with separate gable tops (triangular sections) nail the gable tops to the gables (the tops overhang the gable).

3. Position the second plain side (C) on the floor and bolt to the first plain side

using the coach bolts provided.

4. Select the other plain gable (E) and place on the floor, screw to the plain side (C) as before with two screws, again making sure the sections are flat on the floor.

5. Place a window side (B) on the floor and fix to the plain gable (E) from the inside as before using two coach screws.

6. Fix the other window side (B) to the other plain gable (E) with two coach screws as previous.

7. Before fitting the door section (D) remove the key from the inside of the door and unlock the door, then attach the handle. Slot the door panel between the two window sides and bolt together using two coach bolts per side. Fix the top as before.

8. On 4.2 m long buildings place the roof truss (R) in the middle of the sides and fix with small nails each side. Position the roof purlin (Q) into the slots (it may need trimming to length). It sits upright on the two gables and rests on the truss.

9. Place the roof sections (F) on the building so that the overhang on one side of the roof meets at the apex (the smaller framing goes to the outside). Before fixing check that the roof is square and sitting flat with on sides, if not it is possible the floor is not level and will need packing in one corner.

10. With the roof square check that the sides and gables are sitting flat on the floor. Fix the panels to the floor using two long nails per panel; ensuring that you nail into a floor joist (follow the lines of nails in the floor to locate the joists).

11. Nail the roof sections together (fixing through the purlin) then secure by nailing through the roof into the framing on the sides and gables using 75mm nails.

If the building has been supplied without a verandah, skip to section 17.

12. Butt the verandah floor (large framework) up to the main floor and nail together as with main floor, then select an end verandah rail and screw to the building using two 75mm coach screws. Repeat on the other end rail.

13. Screw the front verandah rails to the end rails again using two coach screws per rail.

14. Place the verandah roof (small framework) on top of the rails, it butts up to the main roof framing at the back and sits flush on top of the rails at the front.

15. Screw the verandah rails to the floor using two coach screws per rail again making sure you screw into a floor joist.

16. To fix the verandah roof first check it is sitting square. Screw to the main roof using 65mm standard screws and nail from above through the framing into the verandah rails.

17. Felt the roof using the small clout nails provided. Start by carefully removing the paper from the felt (K) and roll out flat along the roof so it overhangs each end and approximately 50mm at the side, secure with 3 - 5 evenly spaced nails along the upper edge then fold the felt over the side of the roof and nail every 100 - 150 mm along the edge roof framing working from the middle outwards. Repeat on the other side.

For models with a verandah place another roll of felt on either side of the roof making sure it overhangs the first by at least 100mm, secure with 3 - 5 nails along the upper edge, then nail along the lower edge every 100-150 mm.

Place the third (fifth on models with verandah) roll of felt on the roof just below the apex and nail as before. Place the final strip on the roof dividing the overhang equally to either side; nail down both sides every 100 - 150mm again working from the middle outwards. Fold the ends of the felt and nail into the ends of the framing.

18. Open the trim pack (L) and remove the four fascia boards, nail them to the ends of the roof using small nails, then trim the felt if necessary. Nail on the diamond finials (its best to pre-sink the nails first on a flat surface so as not to split them).

19. Fix the corner strips (long narrow strips) to each outside corner using three small nails per strip (nail at an angle into the framing). Then fix the cover strips (long wide strips) to cover the join where the sides meet again using 40 mm nails.

20. Glaze the building from the outside using the pre fitted beading in the doors and windows. Do not push the beading too tight against the glass or it will crack. You can either use panel pins or silicone sealant to hold the beading in place (not supplied).







We advise you wear gloves when handling glass.

We recommend you treat your building within six months and from then on annually with a recognized brand of spirit based preservative. Barrettine red cedar as used by Albany can be ordered from your local dealer in 5L cans.





These instructions are meant as a guide only we reserve the right to alter design without prior notice.

**Thanks For Buying An Albany Building.
www.albanysheds.co.uk**

ASSEMBLY GUIDE - ALBANY CARLTON - NO VERANDAH



ASSEMBLY GUIDE - ALBANY CARLTON - WITH VERANDAH



ASSEMBLY GUIDE - ALBANY CARLTON - WITH VERANDAH

